

Manual Activation

This writeup will assist you in activating your software when the normal Internet Activation process is not available. By "manual activation" we mean that you will activate the program by giving us an "Manual Activation Request" and we will respond by sending you a "Manual Activation Code".

Note! Manual activation is machine specific. The following steps must be performed on the computer you wish to activate.

(1) Start the Structural Engineering Library. You will see either screen (A) or ©. If you see screen (A) click the button indicated to the right. Otherwise skip to step (3).

(2) Enter your Product Control Code (PCC) and then click the [Check & Save Product Control Code].

(3) Click the [Manual Activation] button and the instructions will be provided to you as shown on screen (D).

(4) A string of information will be created that you need to send to us. Use the "Click here to copy....." Button to store the string in the Windows Clipboard.

Then create an email to "support@enercalc.com" and paste in this string and send the email.

We will send a Manual Activation Code if you have not exceeded your number of allowed activations.

When you receive the Manual Activation Code back from ENERCALC, copy it and paste into the input field 2 of dialog (D).

Click the [Activate] button, and then continue to the program .This activation will remain on this computer indefinitely.

